## OAW COOLER Safety Information

The following safety information must always be followed when working with OAW Coolers.

- Installation instructions should be strictly observed prior to installation of the PARKER cooler.
- To prevent personal injury, always secure the cooler adequately.
- Hydraulic connections should be made by qualified personnel or plumber.
- Cooler surfaces and internal fluids may be hot.
- Check that the cooler is provided with the required caution labels for rotating fan and hot fluid.
- Check the unit for proper port connections prior to assembly, i.e. SAE Oring boss and BSPP ports threads
- Internal pressure should be safely released prior to performing maintenance.
- Maximum internal working pressure for cold-water and a hot-oil circuits are not to exceed 450 psi.
- Make sure to use proper inlets and outlets ports on the cooler which are clearly identified by the Accumulator and Cooler Division sticker affixed to the front of the unit.





## **WARNING - USER RESPONSIBILITY**

FAILURE OR IMPROPER SELECTION OR IMPROPER USE OF THE PRODUCTS DESCRIBED HEREIN OR RELATED ITEMS CAN CAUSE DEATH, PERSONAL INJURY AND PROPERTY DAMAGE.

This document and other information from Parker-Hannifin Corporation, its subsidiaries and authorized distributors provide product or system options for further investigation by users having technical expertise. The user, through its own analysis and testing, is solely responsible for making the final selection of the system and components and assuring that all performance, endurance, maintenance, safety and warning requirements of the application are met. The user must analyze all aspects of the application, follow applicable industry standards, and follow the information concerning the product in the current product catalog and in any other materials provided from Parker or its subsidiaries or authorized distributors. To the extent that Parker or its subsidiaries or authorized distributors provide component or system options based upon data or specifications provided by the user, the user is responsible for determining that such data and specifications are suitable and sufficient for all applications and reasonably foreseeable uses of the components or systems.

© 2021 Parker Hannifin Corporation



Parker Hannifin Corporation

Accumulator & Cooler Division

10711 N. Second Street

Machesney Park, IL 61115

phone 815 636 4100

fax 815 636 4111

www.parker.com